

FROMM

Numbers & Drawings Art. code : FR3.1504

Stretch Wrapping machine's
FR3xx/FR4xx

Version 04 Machines
Version 01 List

Website : www.fromm-stretch.com

Maintenance Advice:

- A = Clean**
- B = Check fixation / tighten**
- C = Check wearing**
- D = Grease**
- E = Control functionality/parameters/settings**

4200 – spareparts (washer/screw/nut/etc.)

4215 – labels clients

4400 – advised sparepart

4401 – wearing part

4402 – construction part

4403 – electrical component

4410 – assembled group FWS