

Parameters Turntable /Carriage FS230
(for inverter N5.5475) FS2.1388

H 93	1
Acc.	4,
Dec.	2.0,
Fr 9	3,
F 4	2,
F 21	50,
F 22	50,
F 23	1,
F 24	1,
F 26	10
F 27	0,
F 28	15,
F 29	15,

If you want change maximum speed:

under 50 hz:

(F21 is 50)

F 25 40 es. 40hz

I 10 40

up 50 hz:

F 21 60 es. 60 hz

F 25 60 es. 60 hz

I 10 60

If you want change minimum speed:

F 26 10  10 hz

8  8 hz