

Wearing&Advice parts FS4xx V05

Code	Description	Price (€)
FS4.1017	Roll (on the base)	
N4.7631	Gear (on the base)	
N5.1184	Motor (on the base)	
FS4.1019	Washer (on the base)	
FS4.1021	Pinion (on the base)	
FS4.1079	Welded gear-shaft group (on the base)	
FS4.1080	Group bracket-rivet (on the base)	
FS4.1155	Shaft (on the base)	
FS4.1210	Proximity turntable (on the base)	
N4.7622	Gear (on the mast)	
FS3.1032	Wheel (on the mast)	
FS1.1215	Washer (on the mast)	
FS4.1065	Shaft plus pinion (on the mast)	
FS3.1029	Group plate with shaft (on the mast)	
FS3.1030	Group plate with pin (on the mast)	
N5.2358	Microswitch (on the carriage)	
N5.2638	Photocell for black film (on the carriage)	
N5.2651	Photocell for black goods (on the carriage)	
N5.2357	Microswitch (on the carriage)	
N5.2355	Microswitch (on the carriage)	
N5.1169	Motor (on the carriage and mast)	
FS4.1148	Shaft (on the carriage)	
FS3.1080	Wheel for belt (on the carriage)	
N4.3209	Belt L=990mm (on the carriage)	
FS3.1083	Shaft (on the carriage)	
N4.3207	Belt L=660mm (on the carriage)	
FS3.1060	Disk (on the carriage)	
FS3.1062	Pin (on the carriage)	
FS3.1064	Shaft (on the carriage)	
FS3.1068	Shaft (on the carriage)	
FS3.1070	Wheel for belt (on the carriage)	
FS3.1090	Shaft (on the carriage)	
FS3.1312	Washer (on the carriage)	
FS3.1316	Rubber roll (on the carriage)	
FS3.1317	Rubber roll (on the carriage)	
FS3.1385	Coupling for electrical motor (on the carriage)	
FS4.1048	Distance piece (on the carriage)	
N4.2204	Roll (on the carriage)	
N4.2205	Roll (on the carriage)	
N51.2293	Black push button (on the carriage)	

N5.2698	Photocell (substitute N5.2667) (on the base, only for horseshoe)	
N5.2643	Photocell catari 90° (on the base, only for horseshoe)	
FS4.1450	Rubbered wheel (on the base, only for horseshoe)	

Wearing&Advice parts FS4xx V05

Code	Description	Price (€)
N51.7111	Keyboard+alphanumeric display (on the electrical cabinet)	
N51.7113	Mainboard FS400/FS401 (on the electrical cabinet)	
N51.7114	Mainboard FS402/FS403 (on the electrical cabinet)	
N5.2269	Red plastic operator 60x60 (on the electrical cabinet)	
N5.2271	Break switch (on the electrical cabinet)	
N51.2218	Mushroom push button (on the electrical cabinet)	
FS4.1244	Inverter U1 Carriage (on the electrical cabinet)	
FS4.1245	Inverter U3 Turntable (on the electrical cabinet)	
FS4.1246	Inverter U2-u4 Film (on the electrical cabinet)	