

FM50 Machine, The carriage does not go down when I press the lever

FAQ:

*The customer reported that the Carriage on the FM50 Easywrap machine 30.2125 does not ascend when the lever is pulled. Can you, please, instruct me how to solve the problem?
The customer reported that the Carriage descends normally. So, it only does not ascend.*

Solution (Inglese):

Look the picture, under the robot.

You should check the two cables, in red in the image below, that operate the lever.

Probably one of the two cables has been released and by not operating the lever, you do not move the gears, consequently the movement is not transmitted to the chain.

Soluzione (Italiano):

Guarda la foto, sotto il robot.

Dovresti controllare i due cavi, in rosso nell'immagine, che azionano la leva.

Probabilmente uno dei due cavi si è sganciato e non azionando la leva, non sposti gli ingranaggi, di conseguenza non si trasmette il movimento alla catena.

